



PANEL DETAILS

MAIN SIGNAL BUTTONS:- 1,2,3,4,6,7,8,9,10,11,12,13,14,19,20,21,22,23,24,27,28,29,30,31,32,36,38,39,40.

CALLING-ON SIGNAL BUTTONS: C-1, C-3, C-27, C-36, C-38, C-40.

129, 131, 136, 138, 201, 202, 203, 204, 205, 206, 207, 208, 210, 212, 214.

POINTS BUTTONS:-

CRANK HANDLE BUTTONS:-CH1,CH2,CH3,CH4,CH5,CH6,CH7,CH8,CH9,CH10

CH20,CH21,CH22,CH23,CH24,CH25,CH26,CH27,CH28.

CRANK HANDLE WELDED WITH KEY

EAST CENTRAL RAIL
DANAPUR DIVISION

FATUHA JN. (FUT)

SR. NU. ML-23B
ECR/SIP/DNR/101/2012
ALT-VII