



GOMOH

GOMOH





ROUTE INDICATOR FOR SIGNAL-188

ROUTE	NOMNECLATUR
1	DN RECEIVING LINE NO.1
2	DN RECEIVING LINE NO.2
3	DN RECEIVING LINE NO.3
4	DN RECEIVING LINE NO.4
5	DN RECEIVING LINE NO.5



MUGHALSARAI
(BHOLIDIH B.H. KM 4.84)

147,149,151,155,157,159,161,163,167,171,173,175,
C-147C-149,C-151,C-155,C-157,C-159,C-161,C-163,
C-167,C-171,C-173,C-137,C-137,C-139,C-139,C-141,
237,239,241,247,249,251,255,257,259,261,263,267,271,
273,275,361,367,369.



FUNCTION OF BUTTONS.

- | | | |
|----------|---|--|
| 1. COGPN | CALLING-ON GROUP BUTTON (RWD) RED WITH WHITE DOT. | 12. MAIN SIGNAL BUTTON (R) RED. |
| 2. EPB | EMERGENCY POINT BUTTON (BL) BLACK. | 13. SHUNT SIGNAL BUTTON (Y) YELLOW. |
| 3. GSB | GROUP RELEASE BUTTON FOR CH (gr) GREY. | 14. POINT BUTTON (BL) BLACK. |
| 4. GSRB | GROUP SLOT CANCELLATION BUTTON FOR CH (gr) GREY . | 15. CRANK HANDLE BUTTON (bl) BLUE. |
| 5. SCB | SIGNAL CANCELLATION BUTTON (R) RED. | 16. GATE BUTTON (gr) GREY. |
| 6. RCB | ROUTE CANCELLATION BUTTON (gr) GREY. | 17. EXIT BUTTON (W) WHITE. |
| 7. OCB | OVERLAP CANCELLATION BUTTON (gr) GREY. | 18. ALTERNATE OVERLAP BUTTON (WBLD) WHITE WITH BLACK DOT. |
| 8. GPB | GROUP POINT BUTTON (BL) BLACK. | 19. POINT BUTTON WITH ROUTE SEC RELEASE (BLWD) BLACK WITH WHITE DOT. |
| 9. ECB | EMERGENCY CANCELLATION BUTTON (BL) BLACK. | |
| 10. XYN | GATE RELEASE CONTROL BUTTON (GREY). | |
| 11. XYRN | GATE RETURN CONTROL BUTTON (GREY). | |