

**PANEL DETAILS**

MAIN SIGNAL BUTTONS:- 1,2,3,4,6,7,8,9,10,11,12,13,14,19,20,21,22,23,24,27,28,29,30,31,32,36,38,39,40.


CALLING-ON SIGNAL BUTTONS:-C-1,C-3,C-27,C-36,C-38,C-40.

SHUNT SIGNAL BUTTONS:-106,107,108,109,110,111,112,113,114,119,120,121,122,123,124, 129,131,136,138,201,202,203,204,205,206,207,208,210,212,214.

POINTS BUTTONS:- 51,52,53,54,55,56,57,58,59,60,61,62,63,64,70,71,72,73,74,75,76,77,78,79,80,81,82,83,84.

CRANK HANDLE BUTTONS:-CH1,CH2,CH3,CH4,CH5,CH6,CH7,CH8,CH9,CH10, CH11,CH12,CH13,CH14,CH15,CH16,CH17,CH18,CH19, CH20,CH21,CH22,CH23,CH24,CH25,CH26,CH27,CH28.

GATE CONTROL BUTTONS:-31.



EAST CENTRAL RAILWAY DANAPUR DIVISION			Lahmad	PANEL SINGALLING PLAN MACL, STD-II(R), CLASS-'B'	FATUHA JN. (FUT)	SR. NO. ML-23
	SR.DSTE/ECR/DNR	ASTE/ECR/DNR	SSE/DRG/DNR			ECR/SIP/DNR/101/2012 ALT-IV