


KUMARBAG STATION कुमारबाग स्टेशन



CLASS OF STATION : B
STD OF SIG & INTERLOCKING: STD-II (R)

EAST CENTRAL RAILWAY SAMASTIPUR DIVISION				STATION WORKING RULE DIAGRAM MACL, STD-II (R) CLASS 'B'	KUMARBAG	SWRD NO.-
	Sr.DSTE/SPJ	DSTE/W/SPJ	JE/DRG	TO SUIT SIP NO. ECR/SIP/SPJ/340/2008 ALT-IX		DY.CSTE/C/I/ SPJ/2009 (RD)/11