



**VDU DETAIL:**

- MAIN SIGNAL BUTTONS : 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 12, 13, 14, 15, 17, 19, 20.  
 CALLING ON SIGNAL BUTTONS : C-1, C-3 & C-20.  
 SHUNT SIGNAL BUTTON: 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 117, 201, 202, 203, 204, 205, 207, 209.  
 POINT BUTTONS : 51, 52, 53, 54, 55, 56, 57, 58, 61, 62, 63, 64, 65, 66, 67, 68, 69 & 71.  
 CRANK HANDLE BUTTONS : CH-1, CH-2, CH-3, CH-4, CH-5, CH-6, CH-7, CH-8, CH-9, CH-10, CH-11, CH-12, CH-13, CH-14.  
 GATE BUTTONS : G-31, G-32, G-33 & G-34.  
 DEAD SHUNT : 301, 302, 303, 304, 306, 308, 310.

EAST CENTRAL RAILWAY SONPUR DIVISION				STATION WORKING RULE DIAGRAM MACL STD-II(R) CLASS-'B'	NARAYANPUR ANANT	SWRD NO.
	DSTE/ECR/SEE	SSE/DRG/SEE	SE/DRG/SEE	TO SUIT SIP NO. ECR/SIP/SEE/139/2019, ALT-III		