


**IN PANEL**  
 MAIN SIGNAL BUTTONS: 1.2.3.4.5.6.8.11.12.  
 CALLING 'ON' SIG. BUTTONS: C-1, C-12  
 POINT CONTROL BUTTONS: 51.52.53.54.55.56  
 GATE CONTROL BUTTONS: G-31, G-32.  
 CRANK HANDLE CONTROL BUTTONS: CH1, CH2, CH3, CH4, CH-5, CH6.



- NOTE:-
1. ABSOLUTE BLOCK SYSTEM OF WORKING WITH NAUGACHHIA & THANABIHPUR STATION.
  2. DL UFSBI WORKING WITH NAUGACHHIA & THANABIHPUR
  3. MAGNETO TELEPHONE PROVIDED BETWEEN PANEL ROOM & GATE No. 13, 13A, 14, 15 & 15A.
  4. CONTROL TELEPHONE PROVIDED IN PANEL ROOM
  5. LED SIGNALS PROVIDED FOR ALL MACL SIGNALS.
  6. SLIDING BOOM PROVIDED IN ADDITION TO L.C. NO. 14 & 15.

EAST CENTRAL RAILWAY  
 SONPUR DIVISION

					STATION WORKING RULE DIAGRAM MACL STD-II(R) CLASS-'B'
DSTE/ECR/SEE	SSE/DRG./SEE	SE/DRG./SEE	TO SUIT SIP NO. ECR/SIP/SEE/169/2009, ALT-VII		

**KHARIK**