


BARKAKANA(BRKA)

DISTRIBUTED E.I. CLASS-'B',STD-III



TO GOMOH
AT KM -100.62 FROM BRKA
NEXT BLOCK STN. ARIGADA(3.33Km)
BRKA AVOIDING(ARGD W/C).

TO DALTONGANJ
AT Km :185.00 FROM BRKA
NEXT BLOCK STN.
ARIGADA(7.078Km) F/BRKA
BRKA AVOIDING(ARGD W/C).

TO MURI
NEXT AT KM:54 FROM BRKA
NEXT BLOCK STN. RAMGARH CANTT
5.00 KM FROM BRKA

TO RANCHI
NEXT BLOCK STN. SIDHWAR
6.405 KM FROM BRKA

PANEL DETAILS

MAIN SIGNAL BUTTONS	1, 2, 5, 6, 7, 8, 9, 10, 12, 14, 16, 18, 19, 20, 21, 22, 23
CALLING - ON SIGNAL BUTTONS	24, 25, 26, 27, 28, 29, 33, 35, 36, 37, 39, 41, 42, 45, 46, C-1, C-5, C-6, C-7, C-8, C-9, C-10, C-11, C-12, C-14, C-16, C-18, C-19, C-20, C-21, C-22, C-23, C-24, C-25, C-26, C-27, C-28, C-29, C-33, C-35, C-36, C-37, C-39, C-42, C-46,
POINT BUTTONS	51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 70, 71, 72, 73, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 95, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114,
CRANK HANDEL CONTROL BUTTONS	CH-1, CH-2, CH-3, CH-4, CH-5, CH-6, CH-7, CH-8, CH-9, CH-10, CH-11, CH12, CH13, CH14, CH15, CH16, CH17, CH18, CH-20, CH-21, CH-22, CH-23, CH-24, CH-25, CH-26, CH-27, CH-28, CH-29, CH-30.
SHUNT SIGNAL CONTROL BUTTONS	107, 108, 109, 110, 112, 114, 115, 116, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 133, 135, 136, 137, 139, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 225, 226, 227, 228, 229, 230, 231, 233, 235.
DEAD SHUNT SIG. BUTTON	302, 303, 304, 305, 306, 307, 308, 309, 310, 312, 314, 316.
DEAD STOP BUTTONS	DS-15
HAND POINT BUTTONS	H.P.-69