

BARKAKANA(BRKA)

DISTRIBUTED E.I. CLASS-B, STD-III




STATION BUILDING BARKAKANA
 KM 100.62 FROM GOMOH
 (CH-100000)

TO GOMOH
 AT KM 100.62 FROM BRKA
 NEXT BLOCK STN. ARIGADAT(3.33km)
 BRKA AVOIDING(ARGD W/C).

TO DALTONGANJ
 AT KM 185.00 FROM BRKA
 NEXT BLOCK STN.
 ARIGADAT(078km) / BRKA
 BRKA AVOIDING(ARGD W/C).

TO MURI
 NEXT BLOCK STN. MARIHAR CANTT
 2.0 KM FROM BRKA

TO RANCHI
 NEXT BLOCK STN. SORAH
 4.60 KM FROM BRKA



PANEL DETAILS

- MAIN SIGNAL BUTTONS 1, 2, 5, 6, 7, 8, 9, 10, 12, 14, 16, 18, 19, 20, 21, 22, 23
- CALLING - ON SIGNAL BUTTONS 24, 25, 26, 27, 28, 29, 33, 35, 36, 37, 39, 41, 42, 45, 46
- POINT BUTTONS C-1, C-5, C-6, C-7, C-8, C-9, C-10, C-11, C-12, C-14, C-16, C-18, C-19, C-20, C-21, C-22, C-23, C-24, C-25, C-26, C-27, C-28, C-29, C-33, C-35, C-36, C-37, C-38, C-42, C-48
- CRANK HANDEL CONTROL BUTTONS 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 70, 71, 72, 73, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 95, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114
- SHUNT SIGNAL CONTROL BUTTONS CH-1, CH-2, CH-3, CH-4, CH-5, CH-6, CH-7, CH-8, CH-9, CH-10, CH-11, CH-12, CH-13, CH-14, CH-15, CH-16, CH-17, CH-18, CH-20, CH-21, CH-22, CH-23, CH-24, CH-25, CH-26, CH-27, CH-28, CH-29, CH-30
- DEAD SHUNT SIG. BUTTON 107, 108, 109, 110, 112, 114, 115, 116, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 133, 135, 136, 137, 138, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 225, 226, 227, 228, 229, 230, 231, 233, 235
- DEAD STOP BUTTONS 302, 303, 304, 305, 306, 307, 308, 309, 310, 312, 314, 316
- HAND POINT BUTTONS DS-15, H.P.-69