


**IN PANEL**  
 MAIN SIGNAL BUTTONS: 1.2.3.4.5.6.8.11.12.  
 CALLING 'ON' SIG. BUTTONS: C-1,C-12  
 POINT CONTROL BUTTONS: 51.52.53.54.55.56.  
 GATE CONTROL BUTTONS: G-31, G-32  
 CRANK HANDLE BUTTONS: CH1. CH2. CH3. CH4. CH5. CH6

- NOTE:-**
1. ABSOLUTE BLOCK SYSTEM OF WORKING WITH CRR & KUE.
  2. D/L BLOCK INSTRUMENT WORKING WITH KUE.
  3. D/L UFSBI BLOCK INSTRUMENT WORKING WITH CRR.
  4. CONTROL PHONE PROVIDED AT PANEL
  5. TELEPHONE PROVIDED BETWEEN SM'S OFFICE & LC.NO. 5E'C', 5F'C', 5G'C'.
  6. AXLE COUNTER PROVIDED FOR LST VEHICLE VERICATION & INTERLOCKED WITH BLOCK INSTRUMENT AT BOTH SIDE .
  7. EOLB & SLIDING BOOM IS PROVIDED ON LC.No.-5F & 5G.
  8. AXLE-COUNTER (SSDAC) PROVIDED IN ADDITION TO EXISTING TRACK CIRCUIT No.011T & 12T.



<b>EAST CENTRAL RAILWAY</b> <b>SONPUR DIVISION</b>		STATION WORKING RULE DIAGRAM MACL STD-II(R) CLASS-'B'	<b>BAKHARI</b>
	DSTE/ECR/SEE    SSE/DRG/SEE    SSE/DRG/SEE	TO SUIT SIP NO. ECR/SIP/SEE/173/2010 ALT-X	SWRD NO. Sr.DSTE/SEE/2013(RD)/3