


IN PANEL
 MAIN SIGNAL BUTTONS: 1.2.3.4.5.6.8.11.12.
 CALLING 'ON' SIG. BUTTONS: C-1,C-12
 POINT CONTROL BUTTONS: 51.52.53.54.55.56
 GATE CONTROL BUTTONS: G-31
 CRANK HANDLE CONTROL BUTTONS: CH1.CH2.CH3.CH4.CH5.CH6.



CRANK HANDLE WELDED WITH THE KEY

- NOTE:-
1. ABSOLUTE BLOCK SYSTEM OF WORKING WITH NAUGACHHIA & THANABIHPUR STATION.
 2. DL UFSBI WORKING WITH NAUGACHHIA & THANABIHPUR
 3. TELEPHONE PROVIDED BETWEEN PANEL ROOM & GATE No. 13, 13A & 15.
 4. CONTROL TELEPHONE PROVIDED IN PANEL ROOM
 5. LED SIGNALS PROVIDED FOR ALL MACL SIGNALS.
 6. SLIDING BOOM PROVIDED IN ADDITION TO L.C. NO. 15.

EAST CENTRAL RAILWAY SONPUR DIVISION				STATION WORKING RULE DIAGRAM MACL STD-II(R) CLASS-'B'	KHARIK
	DSTE/ECR/SEE	SSE/DRG/SEE	SE/DRG/SEE	TO SUIT SIP NO. ECR/SIP/SEE/169/2009, ALT-VII	