


AMLO B.H.
'B' CLASS STD III
Date of commissioning :- 31.08.2006

ASPECT CONTROL CHART									
BERMO END (DN)					PHUSRO END (UP)				
D-8	8A/8B	6			SOUTH LINE				
G	—	G	—	G	GATE HOME				
Y	—	Y	—	R	DIST. OF BRMO				
		2			G	—	3	1A/1B/1C	D-1
					YY	—	YY		G
					Y	—	Y		
Y	—	YWU		R/G	R	—	Y	—	Y
							Y	—	Y
D-4	4				NORTH LINE				
G	—	G	—		GATE HOME				
Y	—	Y	—	R	DIST. OF BRMO				
					G	—	G		
					YY	—	YY		
					Y	—	Y		
					R	—	Y	—	Y
							5A/5B		D-5
							G	—	G
							Y	—	Y
							R	—	Y



PANEL CABIN
MAIN SIGNAL BUTTONS:-1.2.3.4.5.6.7.8.10.
CALLING ON SIGNAL BUTTONS:-C-1.C-4.C-5.C-8.
SHUNT SIGNAL BUTTON:-109.
POINT BUTTONS:-51.52.53.54.55.
CRANK HANDLE BUTTONS:-CH1.CH2.CH3.
KEY LOCK POINT BUTTONS:-P-56. P-57.
GATE CONTROL:-G-31.

SLIDE BOX
8-SLIDES
SPARE:-2. 5. 6.