


BARKAKANA(BRKA)

DISTRIBUTED E.I. CLASS-B',STD-III



ECF STATION BUILDING BARKAKANA
 100.78 FROM KUCERMA
 100.82 FROM GOMOH
 (CHD.000M)



PANEL DETAILS

MAIN SIGNAL BUTTONS

1, 2, 5, 6, 7, 8, 9, 10, 12, 14, 16, 18, 19, 20, 21, 22, 23

CALLING - ON SIGNAL BUTTONS

24, 25, 26, 27, 28, 29, 33, 35, 36, 37, 39, 41, 42, 45, 46
 C-1, C-5, C-6, C-7, C-8, C-9, C-10, C-11, C-12, C-14, C-16, C-18,
 C-19, C-20, C-21, C-22, C-23, C-24, C-25, C-26, C-27, C-28, C-29,
 C-33, C-35, C-36, C-37, C-39, C-42, C-46

POINT BUTTONS

51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68,
 70, 71, 72, 73, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 89, 97,
 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114

CRANK HANDEL CONTROL BUTTONS

CH-1, CH-2, CH-3, CH-4, CH-5, CH-6, CH-7, CH-8, CH-9, CH-10, CH-11, CH12, CH13, CH14, CH15,
 CH16, CH17, CH18, CH-20, CH-21, CH-22, CH-23, CH-24, CH-25, CH-26, CH-27, CH-28, CH-29, CH-30

SHUNT SIGNAL CONTROL BUTTONS

107, 108, 109, 110, 112, 114, 115, 116, 118, 119, 120, 121, 122, 123, 124, 125, 126,
 127, 128, 129, 133, 135, 136, 137, 139, 201, 202, 203, 204, 205, 206, 207, 208, 209,
 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 225, 226, 227, 228, 229, 230, 231, 233, 235

DEAD SHUNT SIG. BUTTON

302, 303, 304, 305, 306, 307, 308, 309, 310, 312, 314, 316

DEAD STOP BUTTONS

DS-15

HAND POINT BUTTONS

H.P.-69